

Barber Pole Inlay Kit



Carefully twist the individual spiral pieces onto the brass tube. For the last piece to fit you might have to remove the brass tube for some extra "wiggle" room.

Once all 4 pieces are assembled and lined up well, slide the brass tube inside, and press both ends together to eliminate any gaps. Apply CA over all seams.

Sand the ends flush with the brass tube
and mount on the lathe for turning
and finishing.